

Figure 3 LED Indicator / Button Pushes

	RED Importan	YELLOW Replaying (Blinking)	GREEN (Blinking)	GHEEN · · · · Ready · · · · ·	COLOR MEANING	
	t Information Stored					
Replaying other than original	Important Information Stored Does not shut off with radio or station change	Blink speed reflects length of time delay	Commercial eliminate mode	Has been reset to live	NOTE	
Long push (>4 seconds) resets function — LED changes to green	Rapid push replays stored information, two rapid pushes slows down replay, three rapid pushes speeds up replay. Long push (>4.0 seconds) resets function —LED changes to Green	Rapid push restarts previous delay; Two rapid pushes replays at slightly accelerated rate and eventually catches up to live. Long push (>2.0 sec) saves information. — LED changes to red. Long push > 4 seconds resets to live. — LED changes to green.	Quick pushes in this mode skips forward 15, 30 seconds, etc. Long button push > 2 seconds resets to live — LED stops blinking.	Each rapid button push increases amount of replay, 10 seconds, 20s, 40s 90s, 3 minutes (or max) — LED changes to yellow. A long button push > 2 seconds initiates Commercial Eliminate Mode — LED blinks.	BUTTON PRESSES	

